
Project 1

Analysis of EEG sleep spindles in COVID-19 survivors

Estimate the averaged slow and fast spindles and localize them in the inverse domain (with Brainstorm) from a high-density EEG recording acquired during a nap in: i. one participant discharged from an intensive care unit (ICU - 023) due to COVID-19 infection between March and May 2020 and ii. one participant never been infected by the virus (CTRL - 033).


Hints:

- 1. Load the data CTRL033_nap.mat and ICU023_nap.mat (204 EEG channels). The sampling rate is 250 Hz.
- 2. Filter the data in the [9-12] Hz and [12-16] Hz frequency ranges. Save in two arrays respectively the slow and fast tracks.
- 3. Identify the spindles: fix the duration of each spindle at 500 ms and use the time instants contained in spindles_timing_033.mat and spindles_timing_023.mat as starting points. Save in two 3-d matrices the signals.
- 4. Compute the average between all the EEG channels for every spindle.
- 5. Compute the spectrum of each signal obtained in point 4. (check pwelch.m function [pxx,f] = pwelch(X1,L,0.6:0.1:20,fs) with X1=data, L=the length of data, [0.6:0.1:20]=frequency range, fs=sampling frequency).
- 6. Plot all the spectra and discard the spindles (trial) with the maximum peak frequency out of range ([9-12] Hz for slow and [12-16] Hz for fast) (see the example below for slow spindle).



- 7. Average the remaining trials considering all the channels and plot the results.
- 8. Average the results obtained at point 7. over time and plot the topographies (eeglab function topoplot).
- 9. Starting from the signal obtained at point 7. localize the activity at 0 ms in the inverse space, using Brainstorm.

See the figure below to check the dimension of the matrices obtained at each point.



Data availability:

https://drive.google.com/drive/folders/1t0kmrh_W7CI5zuTup-H1F2yx1g7dt-E5?usp=share_link